

Preventative Maintenance




Website for videos & manuals

• <u>https://www.turfco.com/service-support/faqs/12/t3200---</u> <u>support-videos-information/</u>

Daily Checklist

- Check and clean spray filter
- Check engine and transaxle oil levels
- Blow off debris and residue from machine









			MON	TUES	WED	THURS	FRI	SAT
1	Ι.	Check engine and transaxle oil levels						
2	2.	Check and clean spray filter						
	3.	Blow off debris and residue from machine						

Completed by:_____

Machine:_____

Date:_____

Weekly Checklist

- Clean carb and choke linkage
- Check engine air filter (replace if dirty, see Briggs engine manual for additional info)
- Check tire pressure (inflate to marked PSI on sidewall of tire)
- Wash machine with water, dry before putting away.



T3200 Weekly Checklist							
1.	Clean carb and choke linkage	WK 1	WK 2	WК 3	WK 4	WK 5	
2.	Check engine air filter and spray filter						
3.	Check tire pressure						
4.	Wash machine with water and blow dry						
Completed by:			1achine:		Date:		

Monthly Checklist

(See additional slides for "how to")

- Inspect under carriage
- Grease machine
- Check steering cables
- Check drive-train

Change engine oil (see Briggs engine manual for more info)



	3200	Mon	<mark>Qʻ</mark> thly C	ı Checklis	st TURFCO ®
1.	Inspect under carriage	JAN	FEB	MAR	Notes:
2.	Grease machine				
3.	Check steering cables				
4.	Check drive-train				
5.	Change engine oil				
Сс	mpleted by:			Machine:	Date:


	3200	Mont	<mark>Q2</mark> thly C	hecklis	st TURFCO®
1.	Inspect under carriage	APR		JUN	Notes:
2.	Grease machine				
3.	Check steering cables				
4.	Check drive-train				
5.	Change engine oil				
Сс	ompleted by:		N	1achine:	Date:

	3200	Mont	<mark>0</mark> 3 thly C	hecklis	st TURFCO ®
1.	Inspect under carriage	JUL	AUG	SEP	Notes:
2.	Grease machine				
3.	Check steering cables				
4.	Check drive-train				
5.	Change engine oil				
Сс	mpleted by:		_ N	1achine:	Date:

	3200	Mont	Q4 thly C	hecklis	st TURFCO ®
1.	Inspect under carriage	ОСТ			Notes:
2.	Grease machine				
3.	Check steering cables				
4.	Check drive-train				
5.	Change engine oil				
Сс	ompleted by:		<u> </u>	1achine:	Date:

Inspect Undercarriage of machine

 Visually inspect underneath machine for debris or leaks




Grease Machine

▶ 7 grease points

* 2 NEW grease point on front tires

Pump grease into zerk until grease comes out seal and wipe off



Front Spindles x 2

Steering Knuckle





Front Tires x 2**

Remove metal cap and add grease until full. Reinstall cap.



Idler Arm - NEW



Front Axle - Pivot

Inspect Steering Cables

Step 1: Apply tape measure as seen in illustration to right





- Step 2: Push steering cable towards frame to take measurement. (illustration to left)
 - Measurement should be no more than a 1 1/2". If measurement is great than 1 ½" than proceed to step 3
 - If measurement is less than 1 ½" you may proceed to the next task in your monthly inspection, you have completed the steering cable task and in good shape as it stands

(Continue to step 3)

Inspect Steering Cables (continued)

- Step 3: Loosen jam nut with two ½" wrenches
 - Hold cable with hand or pliers and tighten cable end
 - Reminder same adjustment should be made to both sides, not just one side





Inspect Drive-train

- Apply tape measure to spring – measure the spring length. Measurement should be at 5.375". Figure (a)
- Loosen inside jam nut (two 3/4" wrenches) 4 to 5 revolutions, tighten outside nut to increase tension. Figure (b)
 - Avoid twisting the spring when tightening
- Tighten inside jam nut when you achieve proper tension

